

BW-2500  
**PREMIER**

## USER INSTRUCTIONS

**CONGRATULATIONS** on your purchase of the PREMIER remote vehicle alarm. You now own the most reliable security system available today, utilizing the latest state of the art technology. It is *American made*, designed and engineered by leading experts in the security industry.

The PREMIER comes with two 2-button code learning remote transmitters, flashing L.E.D., dual electronic sensor, and many additional features. It can be programmed as a manual or passive system. A number of these safety and convenience features can be programmed into your system either by the installing dealer, or in some cases yourself (explained below). With minimum care and upkeep, this alarm will give you many years of service and protection. *Read the following information carefully.* It will help you get the best from your system.

### A) MANUAL OPERATION

**1) TO ARM** – Press the left button. You will hear 1 chirp and the L.E.D. will flash slowly 10 seconds after button is pressed. This indicates your system is armed.

**2) TO DISARM** – Press the left button. You will hear 2 chirps and the L.E.D. will no longer flash indicating the system is disarmed. If doors are not open before 30 seconds, alarm will re-arm itself.

### B) PASSIVE OPERATION

**1) TO ARM** – If your installing dealer has installed the PREMIER as a passive system, the alarm will arm automatically approximately 30 seconds after the last door is closed. (Note: you can also arm immediately by pressing the left button as in #1 above).

**2) TO DISARM** – Disarm system same as in #2 above.

**3) VALET** – Your dealer installed a valet (push button) switch in a convenient location in the dashboard area. To activate the valet, push for 5 seconds prior to turning off the engine. The L.E.D. will stay on (non-flashing) while the vehicle is in Valet. You can now leave the vehicle without arming the system. While in valet, with the alarm inactive, you can still lock/unlock your doors with the remote transmitters. See section C. To deactivate from the valet mode, turn on the ignition and press the valet switch for 5 seconds.

### C) DOOR LOCK AND UNLOCK

**1)** If your vehicle has electronic (automatic) door locks, and your dealer connected them to the alarm, the

PREMIER will also lock when arming and unlock when the system is disarmed in either manual or passive operation.

**2)** Your system can be programmed by the dealer *not to lock* in the passive mode. In this case your system will arm passively, but you must press the left button to lock the vehicle.

**3)** Your door locks can also be programmed by your dealer to lock when the ignition is turned on and to unlock when the ignition is turned off.

If you have questions, ask your dealer to explain these very convenient features to you.

### D) AUDIO-VISUAL WARNING INDICATORS –

When disarming, if you hear 3 chirps (instead of the normal 2) and the L.E.D. is flashing rapidly, it means either an entry violation was attempted or your vehicle was bumped hard enough to cause the alarm to trigger (check your vehicle to make sure everything is working and there is no damage).

**E) REMOTE PANIC** – An important safety feature on your PREMIER system is a remote panic which will trigger your alarm a substantial distance away. Press left button for 3 seconds until siren sounds. To stop the siren, press the left button.

**F) STARTER INTERRUPT** – As added protection, the PREMIER has a built-in starter interrupt. When the system is armed, the vehicle cannot be jump started, hot wired, or started with a key. This makes it extremely tough on any theft attempt. When you use your transmitter to disarm the system, the vehicle can then be started normally.

**(Continued on Reverse Side)**

**Please Keep For Future Reference**  
**TO USE THE CODE LEARNING**  
**SEQUENCE FOLLOW THIS PROCEDURE:**

1. Turn the ignition switch ON/OFF 3 times, leave ignition ON the 3rd time. The SIREN will chirp once and the Door Locks (if connected) will LOCK.
2. Within 5 SECONDS, press and HOLD the Valet Switch for 5 seconds, the SIREN will Chirp 3 Times and the L.E.D. will turn SOLID. The System is now in Code Learning Mode.

**(Continued on Reverse Side)**



**Note:** The valet switch is also an emergency override switch. If you lose or damage your re-mote transmitter, or if there is a malfunction in the system, you can still use your vehicle even if armed, utilizing the following procedure. Open the door (the siren will sound and the *starter interrupt* will be in effect), turn ignition switch to "on" position, and press the push button switch to "on" as well (your dealer will show you where the switch is on or near the dash). The siren will stop and the *starter interrupt* mode overridden, allowing you to start the vehicle. See your dealer as soon as possible to replace transmitter or correct any malfunction.

**G) AUTOMATIC RESET** – If your alarm is set-off, it will automatically rearm itself after the cycle is completed.

**H) TEMPORARY CHIRP DELETE** – The PREMIER alarm system is designed to chirp when the alarm is armed or disarmed. There may be times when the *chirp* sound is inconvenient (late at night for example). You can temporarily stop the *chirp* by pressing the right button immediately preceding the press on the left button when arming or disarming. This eliminates the *chirp* that time only. Each time you wish the *chirp* eliminated, the above procedure must be used.

**I) DOME LIGHT TURN ON** – If you have an interior light, the PREMIER can be set to turn it on temporarily when the disarm button is pressed. This allows you to see in and around the vehicle as you approach it.

**J) FAULTY SENSOR BY PASS** – If a sensor malfunctions, it will be bypassed automatically, and not stop the use of the alarm. Therefore your vehicle is still protected. However, bring your vehicle into your dealer as soon as possible to fix the problem.

#### **K) AUXILIARY FEATURES**

**1) MULTI-CAR USE** – The PREMIER remote transmitters can be programmed to work with control modules of other PREMIER alarms. For example, you can use the left button to send appropriate signals to your car, and the right button to use for the PREMIER alarm in a second car.


Ask your dealer about this feature.

- 3.** Press Button #1 of either transmitter for Car #1 operation, the system will respond with either 1 or 2 Siren Chirps. The system has now learned the transmitters code. For a two car operation, follow the steps 1 and 2 for second vehicle using button #2 of transmitter.

**Turn OFF the ignition switch.  
The system is now ready to be tested.**



12753 Moore Street  
Cerritos, California 90703



**2) AUTOMATIC TRUNK OPENER** – The 2nd channel (right button) can be programmed to open the trunk (if the vehicle has automatic trunk release), and other quick release accessories.

**3) ADDITIONAL USES** – The 3rd channel (pressing left & right buttons at the same time) can control remote starter, automatic

window roll-up and more. These are accessories available from your BLACK WIDOW dealer who will explain how these accessories will work on your vehicle.

#### **L) PROGRAMMABLE MULTI-TONE SIREN** –

Your BWV-2500 PREMIER comes with a Multi-tone siren which can be programmed to sound from 1 to 6 tones. On the top of the siren is a rubber grommet, underneath which are 6 jumper contacts. You can program the siren by removing the rubber grommet and removing or adding jumper contacts. Your dealer can show you how to program your siren, as well as all the other BLACK WIDOW accessories available to you.

#### **ACCESSORIES AVAILABLE FOR YOUR BLACK WIDOW BW-2500 PREMIER:**

**MAS-2** Radar Field Disturbance Sensor

**BWS-500** Battery Back-Up

**RAS-101** Remote Auto Start

**TR-100** Trunk Release Module

**WRM-2** Window Roll-Up Module

**BWS-390** Leather Transmitter Case

**PDL-50** Power Door Lock Actuator

#### **LIMITED LIFETIME WARRANTY**

The Black Widow Division of DLC, Inc. warrants to the original purchaser that the vehicle alarm system purchased will be free from defects in workmanship.

If it is determined that a defect exists, at our option, we will repair defective parts or replace the system. If product is defective within one (1) year from date of purchase, item will be repaired or replaced at no cost to original purchaser. If product is defective after one (1) year from date of purchase, ship defective unit prepaid to Black Widow Division, DLC, Inc. along with \$20.00 U.S. (\$30.00 Canadian) cashier's check or money order to cover cost of handling.

**Proof of purchase by the original owner must accompany warranty request before service is rendered.**

This warranty covers normal use. It does not cover damage from alteration, misuse, abuse, accident, improper installation or maintenance. Warranty does not cover transmitter batteries or cases. This warranty gives you specific legal rights and you may have rights which vary from state to state. If you have any questions, contact your authorized Black Widow dealer.

#### **DLC/U.S.A.**

12753 Moore Street  
Cerritos, California 90703