

Factory Keyless Upgrade

USER INSTRUCTIONS

Congratulations on your purchase of the Factory Keyless Upgrade factory keyless upgrade security system. Your Factory Keyless Upgrade is manufactured in the U.S.A. and designed by leading security experts using the latest state of the art technology.

The Factory Keyless Upgrade is designed to interface with your existing factory keyless system and will not interfere with its operation. The system comes with an L.E.D. and override switch. This system may also come with dual zone shock sensor and multi tone siren.

Arming Operation: Simply press the lock button on your factory remote and you will hear one chirp from your horn/siren, your parking lights will flash one time (optional). Your doors will lock, the L.E.D. will turn on solid for 10 seconds then it will start flashing slowly. Once the LED starts slowly flashing your system will be fully armed.

2

Disarming Operation: Press the unlock button on your factory remote, the siren/horn will chirp twice, your parking lights will flash twice (optional). The L.E.D. will stop flashing, the doors will unlock and your system is disarmed. (See Security Modes)

Passive Arming: If your installing dealer installed the system to passive arm, the system will arm 30 seconds after the last door has been closed. It will not lock the doors. To disarm the system simply follow the disarming operation above. When the system is in the pre-arm mode the led will flash rapidly to let you know that it ready to arm the system in 30 seconds.

Valet Mode: Valet mode will keep your alarm system from passive arming (if programmed to be passive arming), if you need to have your vehicle serviced, or run it through a car wash etc. To put your vehicle in Valet Mode, turn the ignition key on and press and hold your valet/override switch in for approximately 5 seconds, the L.E.D. will turn on solid. You vehicle's system is in Valet Mode. Deactivate Valet Mode: It will stay in Valet until you repeat the procedure and the L.E.D. will turn off.

Security Modes: Your system can be programmed 3 different ways depending on the vehicle and the additional security components that are added to it.

Security level 1: The alarm system will simply turn off when you press unlock button on your remote.

Security level 2: If you return to your vehicle and press the unlock button to disarm the system and hear 4 double chirps

from your siren or horn it means the system has been triggered. To disarm the system once it has been triggered you must open the door (the siren/horn will sound) and you must turn the ignition key on and press the override/valet switch.

Security level 3: If you return to your vehicle and press the unlock button to disarm the system and hear 4 double chirps from your siren or horn it means the system has been triggered. When you open the door, the siren/horn will chirp to let you know that you have 10 seconds to turn the ignition key on and press the override switch.

LED Status Modes:

Valet= Solid

Pre Arm Active=Solid for 10 seconds

Armed=Slow flash

Disarmed=Off

Pre Arm Passive= Rapid flash

System triggered while away=Slow double flash

Operating Override/Valet Switch

Valet=Ignition switch on, press override/valet switch for 5 seconds.

Disengage Valet=repeat above process.

Manual Override System=Ignition On press switch

Limited Lifetime Warranty

DLC, Inc. warrants to the original purchaser that the vehicle alarm system purchased will be free from defects in workmanship. If it is determined that a defect exists, at our option, we will repair defective parts or replace the system. If product is defective within one (1) year from date of purchase, item will be repaired or replaced at no cost to original purchaser. If product is defective after one (1) year from date of purchase, ship defective unit prepaid to DLC, Inc. along with \$20.00 U.S. (\$30.00 Canadian) cashier's check or money order to cover cost of handling.

Proof of purchase by the original owner must accompany warranty request before service is rendered.

This warranty covers normal use. It does not cover damage from alteration, misuse, abuse, accident, improper installation or maintenance. Warranty does not cover transmitter batteries or cases. This warranty gives you specific legal rights and you may have rights which vary from state to state. If you have any questions, contact your authorized dealer.